


Tri-Vista 21

*Multistandard 96-192kHz 24 Bit
Digital-to-Analog Convertor*



INSTRUCTIONS FOR USE

MUSICAL FIDELITY

SAFETY INFORMATION

IMPORTANT! (U.K. only)

This unit is supplied in the U.K. with a mains lead fitted with a moulded 13 amp plug. If, for any reason, you need to cut off this plug, please remove the fuse holder and dispose of the plug safely, out of reach of children. ***It must not be plugged into a mains outlet.***

The wires in the mains lead supplied with this appliance are coloured in accordance with the following code:

Green and yellow.....Earth
Blue.....Neutral
Brown.....Live

WARNING - This appliance must be earthed

As the colours of the wires of the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured green-and-yellow must be connected to the terminal in the plug which is marked with the letter E or coloured green or green-and-yellow, or by the earth symbol:



The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

If connecting to a BS1363 plug, a 13 amp fuse must be used.

WARNING:

Any modification to this product not expressly approved by Musical Fidelity who is the party responsible for standards compliance could void the user's authority to operate this equipment.

GENERAL ADVICE

INSTALLATION PRECAUTIONS and USER INFORMATION

Your new Tri-Vista 21 DAC is designed and built to provide trouble-free performance, but as with all electronic devices it is necessary to observe a few precautions:

Heed all warnings shown on the back of the product.

Only connect the Tri-Vista 21 DAC to a mains outlet having the same voltage as marked at the back of the unit.

Always ensure that when disconnecting and reconnecting your audio equipment the mains supply is switched off.

Position the mains lead and signal interconnects where they are not likely to be walked on or trapped by items placed on them.

*Do not use near water, or place water-filled containers on the product, for example, flower vases or potted plants. **If water does spill into the Tri-Vista 21 DAC, immediately pull out the mains plug from the wall socket and inform your dealer, who should then check the unit before further use. Entry of liquid into the equipment is dangerous, and may cause electric shock or fire hazard.***

Do not place the unit near heat sources such as radiators, direct sunlight or other equipment.

Do not remove covers or try to gain access to the inside. There are no internal user adjustments. Refer all service work to an authorised Musical Fidelity agent.

NOTE: Unauthorised opening of the equipment will invalidate any warranty claims.

Dust regularly with a soft duster or soft brush, but be careful when using cleaning or polishing agents - they may harm the surface finish.


The electronics in modern hi-fi equipment is complex and may, therefore, be adversely affected or damaged by lightning. For protection of your audio system during electrical storms, remove the mains plugs and disconnect any aerial lead.

If after-sales service is required, to help your dealer identify the Tri-Vista 21 DAC please quote the serial number located on the rear panel of the unit.

RADIO FREQUENCY INTERFERENCE (R.F.I)


This product has been tested to ensure that its operation is not adversely affected by normal background levels of R.F.I., and that it does not itself generate excessive amounts of interference. However, if a problem persists, please contact your Musical Fidelity agent.

CONNECTIONS AND FACILITIES



- 1 Power on indicator LED
- 2 Power on/off switch
- 3 96kHz indicator light
- 4 192kHz indicator light
- 5 Co-axial input indicator light
- 6 Optical input indicator light
- 7 Data locked indicator light

- 8 Analogue output - right
- 9 Analogue output - left
- 10 Digital input - optical
- 11 96/192kHz selector switch
- 12 Digital input - co-axial
- 13 Digital output - co-axial
- 14 IEC mains inlet



CONNECTIONS AND OPERATION

All input, output and power connections should be made with the mains power switched OFF.

INPUT CONNECTIONS

The Tri-Vista 21 DAC will convert digital data from any CD, SACD or DVD-audio source to analog audio, but not data from AC3, Minidisc, or MP3 formats.

However, the digital output socket will loop any selected digital source for external processing if required.

Connect the digital output from your CD or DVD player (or other digital source) to one of the Tri-Vista 21 DAC's inputs.

The Tri-Vista 21 DAC has two inputs, one an optical "Toslink" and the other an S/PDIF* co-axial RCA socket. Either one is automatically selected by the presence of a digital signal, but if both are accidentally connected at the same time, priority is given to the first of the two inputs presented.

* *Sony/Philips Digital Interface Format*

OUTPUT CONNECTIONS

Using good quality co-axial audio leads, connect left and right audio outputs from the analogue output sockets on the back panel of your Tri-Vista 21 DAC to any line level input in your amplifier system, for example the CD or auxiliary sockets.

The co-axial RCA digital output can also be connected to suitable external digital equipment if required.

BEFORE SWITCHING ON

Plug the accessory IEC mains lead into the rear panel socket, then the other end into a wall outlet.

Turn the volume control low on your audio system, and switch on its power.

OPERATION

Press the **POWER** button on the Tri-Vista 21 DAC - the power indicator LED on the front panel will light confirming that the unit is now ready for use.

Start the required digital source playing.

The **LOCKED** data indicator LED on the front panel will light to show that the Tri-Vista 21 DAC has successfully locked on to the incoming data stream, and either the **CO-AXIAL** or **OPTICAL** LED shows which input has been selected.

If there is no incoming digital data to either input, the **CO-AXIAL** and **OPTICAL** LEDs will flash alternately, and the **LOCKED** LED will flash more rapidly.

The appropriate **96kHz** or **192kHz** light will indicate which sample rate is in use, but this can be changed by pressing the **SELECTOR** push-switch at the rear of the unit as required.

Now adjust the volume control on the audio system to obtain the preferred sound level.

Tri-Vista 21

Multistandard 96-192kHz 24 bit Digital-to-Analog Convertor

DAC architecture	24-bit Delta-Sigma (Bitstream) Dual differential 8 times oversampling, 96 / 192kHz switchable
Sampling frequencies	8 to 108kHz
Data types	16, 20, 24 bit word lengths
Inputs:	RCA 75Ω, S/PDIF TOSLINK optical
Outputs	RCA left and right analog audio, RCA digital loop out
Output impedance	50 Ohms
Frequency response	10Hz to 20kHz \pm 0.0dB
Signal/noise ratio	114dB "A"- weighted
Total harmonic distortion	< 0.0025% 10Hz to 20kHz
Total correlated jitter	< 135pS
Channel separation	< 109dB 20Hz to 20kHz
Linearity	< 0.2dB down to -100dB
Audio output at digital 0dB level	2.17 Volts RMS at 1kHz nominal
Power requirements	100, 115 or 230Volts AC 50 / 60Hz (Voltage factory pre-set for country) 30 Watts
Dimensions	440mm, 17.3 inches wide 105mm, 4.13 inches high (including feet) 375mm, 14.8 inches deep (including terminals)
Weight	13.15 kg, 29 lbs unit only, unboxed 15.2 kg, 33.5 lbs in shipping carton
Standard accessories	IEC type mains lead



Musical Fidelity reserves the right to make improvements which may result in specification or feature changes without notice.