


V-CAN_{II} Headphone Amplifier Instructions



Connections

All connections must be made before the mains adaptor is plugged in, and before any amplifier connected is switched on. Always switch off the equipment attached to the V-CAN_{II} before connecting or disconnecting power, changing leads or inputs.

Inputs

Using good quality RCA leads (not supplied), connect the left and right outputs from a CD player or other audio source to the V-CAN_{II} **LINE INPUT** sockets. If connecting into an existing system, the V-CAN_{II} can conveniently be connected to the TAPE REC outputs of any pre- or integrated amplifier. If the TAPE REC outputs are still required by e.g. tape or CD recorder, then the LINE OUT of the V-CAN_{II} replicates the original TAPE REC output and can be used accordingly.

Outputs

Two headphone sockets are available to allow a greater range of headphones to be used without need of adaptors. Connect headphones into the correct output socket of the V-CAN_{II}.

Power

Plug the DC connector lead from the power supply unit into the V-CAN_{II} power inlet socket, and plug the adaptor itself into a convenient wall mains outlet. The blue LED will light to confirm the unit is ready for use.

Use

Adjust the volume control for a comfortable listening level, sit back and enjoy the music.

These products have been designed so that it may be left on indefinitely, but please note that the mains adaptor may become warm to the touch - this is normal.

Introduction

Thank you for purchasing the V-CAN_{II} headphone amplifier. We sincerely hope that it will bring you many years of outstanding listening pleasure.

Installation Precautions

Your new V-CAN_{II} is designed and built to provide trouble-free performance, but as with all electronic devices, it is necessary to observe a few precautions:

Do not use the V-CAN_{II} near water. The unit must not be exposed to dripping or splashing and no objects filled with liquids, such as vases, must be placed on the unit.

Keep the V-CAN_{II} away from heat such as radiators. No naked flame sources, such as lighted candles, should be placed on the unit.

Power Supply Note:

Only use approved *Musical Fidelity* DC power supply. The use of other adaptors or supplies could seriously damage the V-CAN_{II}.

This Hi-fi product has been tested to ensure that its operation is not adversely affected by normal background levels of Radio Frequency Interference (R.F.I.), and that it does not itself generate excessive amounts of interference. However, if a problem persists, please contact your Musical Fidelity agent.


Never open the case of the V-CAN_{II} yourself, as this will invalidate the guarantee. Place all connecting cables where they are not likely to be walked on or trapped by items placed on them.

The V-CAN_{II} will operate in accordance with its specifications within the following environmental range:

Temperature 5 to 45 degrees Celsius
Humidity 10 to 90% non condensing

There are no user adjustments inside. Please refer all service work to an authorised Musical Fidelity agent.

Front and back connections



Basic problem-solving with an amplifier is similar to troubleshooting other electrical or electronic equipment.

Always check the most obvious possible causes first, such as the following examples:

Problem	Probable Cause	Remedy
No power	Power supply not switched on.	Check power supply is plugged in and switched on
	Power plug is not fully inserted into rear socket	Plug in securely
No sound	Wrong connections between input source and the V-CAN _{II}	Check audio input lead connections
	Wrong connections between the V-CAN _{II} output and headphones	Check headphone lead is connected and secure
	Volume turned right down	Check volume is adjusted accordingly. Take care not to turn up too high!
Hum	Audio connector plug not fully pushed in	Insert plug securely

If none of these actions affect a cure, please contact the dealer, or an authorised Musical Fidelity service agent. Remember; never open the case of the V-CAN_{II}, as this will invalidate the guarantee.

Specifications:	Power	0.25W /channel	into 32 Ohms
	Output devices	2	per channel
	Output impedance	5Ω	
	Total harmonic distortion	<0.005% typical	20Hz-20 kHz
	Signal/noise ratio	>109dB	'A' weighted
Connections:	Input impedance	25 KΩ	
	Frequency response	+0, -1dB	20Hz to 80 kHz
	Power requirement:	12V DC	500mA
	Line level inputs:	1 pair line level RCA connectors,	
Dimensions:	Line level outputs:	1 pair RCA [connected to inputs as loop through]	
	Headphone outputs	1 Stereo Jack socket 6.35mm, ¼"	
	Power input	1 Stereo Jack socket 3.5mm, ¼" 1.3mm DC power socket	
Weight:	Length	180mm	7" including terminals and volume
	Width	95mm	3 ¾"
	Height	40mm	1 ½" including "feet"
Accessories (supplied)	Unit alone	350g	12¼oz
	Total packed carton	1Kg	2 ¼lbs
Accessories (supplied)	Power Supply Unit	12V DC	500mA
	Leaflet	V-CAN _{II}	Instructions

Musical Fidelity reserves the right to make improvements which may result in specification or feature changes without notice. E&OE.



Item disposal information for Europe



DISPOSAL

The crossed out wheeled bin label that appears on the back panel of the product indicates that the product must not be disposed of as normal household waste. To prevent possible harm to the environment please separate the product from other waste to ensure that it can be recycled in an environmentally safe manner. Please contact your local government office or your retailer for available collection facilities.



DISPOSITION

La poubelle sur roulettes barrées X, qui apparaît en logo sur le panneau arrière du produit, indique que celui-ci ne doit pas être traité comme un déchet domestique commun. Afin de protéger l'environnement, ce produit électronique devra être géré séparément et donc recyclé selon les nouvelles normes Européennes Rohs concernant les déchets d'appareils électroniques. Prière de contacter les services concernés gouvernementaux ou votre point de vente pour l'élimination et l'enlèvement de déchets électroniques équipés de composants électroniques.



DISPOSAL

La etiqueta cruzada hacia fuera del compartimento que aparece en el panel trasero del producto indica que el producto no se debe reciclar como basura normal de la casa. Para prevenir daños posible al ambiente separe por favor el producto de otras basura para asegurarse de que puede ser reciclada de una manera ambientalmente segura. Entre en contacto por favor a su oficina gubernamental local o a su minorista para las instalaciones disponibles de la colección.



RIFIUTI

L'etichetta del cassonetto barrato riportato sul retro dell'apparecchio indica che il prodotto non deve essere smaltito tramite la procedura normale di smaltimento dei rifiuti domestici. Per evitare eventuali danni all'ambiente, separare questo prodotto da altri rifiuti domestici in modo che possa venire riciclato in base alle procedure di rispetto ambientale. Per maggiori dettagli sulle aree di raccolta disponibili, contattate l'ufficio governativo locale od il rivenditore del prodotto.



FACHGERECHTE ENTSORGUNG

Das auf der Geräterückseite angebrachte Label deutet darauf hin, dass das Produkt nicht mit konventionellem Hauskehricht entsorgt werden darf. Um Schäden und Verschmutzungen an Umwelt und Mensch zu vermeiden, muss das Produkt fachgerecht entsorgt und von anderem Abfall getrennt werden. Wenden Sie sich bei Fragen hierzu an Ihren Fachhändler oder an eine öffentliche Informationsstelle.



AFVAL

Het label op de achterzijde van dit apparaat, een afvalbak op wielen met een kruis doorgehaald, geeft aan dat dit apparaat niet samen met gewoon huishoudafval mag worden weggegooid. Om mogelijke schade aan onze leefomgeving te voorkomen dient dit apparaat, gescheiden van gewoon huishoudelijk afval, te worden afgevoerd zodat het op een milieuvriendelijke manier kan worden gerecycled. Neem voor beschikbare inzamelplaatsen contact op met uw gemeentelijke reinigingsdienst of met uw elektronica leverancier.



HÄVITÄMINEN

Yrüksäätua jättesäätua kuvaava tarra tuotteen takalevyssä kertoo, että tuotetta ei saa käsitellä normaalina talousjätteenä. Ympäristön suojelemiseksi on tuote pidettävä erillään muusta jätteestä ja se on kierrätettävä ekologisesti kestävässä tavalla. Ota yhteyttä laitteen myyjään tai Pirkanmaan Ympäristökeskukseen lähimmän kierrätyskeskuksen löytämiseksi.



AFSKAFNING

Logoet med en skraldespand med kryds over på bagsiden af apparatet indikerer at dette produkt ikke må kasseres som normal husholdningsaffald. For at forebygge mulig skade på miljøet, bedes De separere dette produkt fra andet affald, og sikre at det bliver genbrugt på en miljørigtig måde. Kontakt venligst de lokale myndigheder eller din forhandler for oplysning om nærmeste tilgængelige opsamlingssted for elektronikaflald.



ΔΙΑΔΙΚΑΣΙΑ ΑΠΟΡΡΙΨΗΣ

ΤΟ ΣΗΜΑ ΜΕ ΤΟΝ ΔΙΑΓΕΓΡΑΜΜΕΝΟ ΤΡΟΧΗΛΑΤΟ ΚΑΔΟ ΑΠΟΡΡΙΨΑΤΟΝ ΣΤΗΝ ΠΙΣΩΤΗ ΟΨΗ ΤΟΥ ΜΗΧΑΝΗΜΑΤΟΣ ΔΗΛΩΝΕΙ ΟΤΙ ΤΟ ΠΡΟΪΟΝ ΑΥΤΟ ΔΕΝ ΠΡΕΠΕΙ ΝΑ ΔΙΑΧΕΡΙΣΘΕΙ ΣΑΝ ΣΥΝΗΘΙΣΜΕΝΟ ΟΙΚΙΑΚΟ ΑΠΟΒΛΗΤΟ. ΠΡΟΣ ΑΠΟΦΥΓΗ ΕΝΔΕΧΟΜΕΝΗΣ ΕΠΙΒΑΡΥΝΣΗΣ ΤΟΥ ΠΕΡΙΒΑΛΛΟΝΤΟΣ, ΞΕΧΟΡΙΣΤΕ ΤΟ ΠΡΟΪΟΝ ΑΠΟ ΤΑ ΆΛΛΑ ΑΠΟΡΡΙΨΑΤΑ ΩΣΤΕ ΝΑ ΕΞΑΦΑΝΙΣΘΕΙ Η ΑΝΑΚΥΚΛΩΣΗ ΤΟΥ ΜΕ ΤΟΝ ΠΡΕΠΟΝΤΑ ΤΡΟΠΟ. ΠΑΡΑΚΑΛΟΥΜΕ ΝΑ ΕΠΙΚΟΙΝΩΣΕΤΕ ΜΕ ΤΗΝ ΤΟΠΙΚΗ ΥΠΗΡΕΣΙΑ ΑΝΑΚΥΚΛΩΣΗΣ Η ΜΕ ΤΟ ΚΑΤΑΣΤΗΜΑ ΑΓΟΡΑΣ ΓΙΑ ΠΕΡΙΣΣΟΤΕΡΕΣ ΛΕΠΤΟΜΕΡΕΙΕΣ.

MUSICAL FIDELITY

Units 24-26
Fulton Road
Wembley
HA9 0TF
England
(+44) 208 8900 2866
<http://www.musicalfidelity.com/>

Manual issue 02